ZENITH data systems

ZT-1

PERSONAL INFORMATION TERMINAL

Quick Reference Card

Copyright © 1982
ZENITH DATA SYSTEMS
Saint Joseph, Michigan 49085

597-2756

START-UP

Turn on Monitor power
Turn on Printer (if connected)
Press HELP key
    Main Menu display appears
Press a LETTER to dial - or -
Select ACTION: follow prompts

MAIN MENU ACTIONS

F1 — MANUAL dial
F2 — CHANGE directory
F3 — SETUP
F4 — ON LINE

DEFAULT PARAMETERS (on reset)

(Use Setup Action to change)

* Time Set (00:00:00)
Auto LF on CR (off)
Auto CR on LF (off)
Wrap at end of line (on)
* Cursor (blink)
Auto repeat (on)
Key click (on)
(Full) Duplex
Clock Display (on)
* Auto answer after (0) rings
Wait (10) seconds for answer
/ Pause (1.2) sec.
Handshaking (XON/XOFF)

* If values are stored in RAM, Reset will only change those which are indicated.

ESCAPE SEQUENCES

Cursor Control Functions

Cursor up one line (Up Arrow)	ESC A
Cursor down one line (Down Arrow)	ESC B
Cursor to right (Right Arrow)	ESC C

Cursor Control Functions (Cont'd.)

Cursor to left (Left Arrow)	ESC D
Cursor to home	ESC H
Save cursor position	ESC j
Cursor to saved position	ESC k
Steady cursor	ESC x;
Blinking cursor	ESC y;
Disable cursor	ESC x 5
Enable cursor	ESC y 5

Edit and Erase Functions

Clear screen display	ESC E
Erase to beginning of display	ESC b
Erase to end of page	ESC J
Erase to beginning of line	ESC o
Erase to end of line	ESC K
Erase entire line	ESC I
Insert line	ESC L
Delete line	ESC M

Keyboard Control

Disable key click	ESC x 2
Enable key click	ESC y 2
Disable auto-repeat keyboard	ESC x <
Enable auto-repeat keyboard	ESC y <
Auto line feed on return	ESC x 8
Cancel auto line feed	ESC y 8
Auto return on line feed	ESC x 9
Cancel return on line feed	ESC y 9
Enter reverse video mode	ESC p
Exit reverse video mode	ESC q
Wrap around at end of line	ESC v
Discard at end of line	ESC w
Enter graphic mode	ESC F
Exit graphic mode	ESC G
Reset to power-up states	ESC z

Display Control

Normal display	ESC s 0
Reverse video display	ESC s 1
Blinking display	ESC s 2

Display Control (Cont'd.)

Reverse video + blinking	ESC s 3
Half intensity display	ESC s 4
Reverse video + half intensity	ESC s 5
Blinking + half intensity	ESC s 6
Reverse + blinking + half	ESC s 7
Enable status line	ESC y =
Disable status line	ESC x =

Clock Functions

Enable clock display	ESC c
Disable clock display	ESC d
Send time to host	ESC e
Set the time (HHMMSS)	ESC X

ON LINE Control Functions

(depend on host)

Stop the display	CTRL S
Restart the display	CTRL Q

Other Functions

Transmit status line	ESC]
Transmit page	ESC #
Transmit this line	ESC ^
Transmit character at cursor	ESC _
Transmit page to printer	ESC \
Printer ON (When Off Line)	ESC x:
Printer OFF (When Off Line)	ESC y:
Reset Terminal	CTRL SHIFT ESC
Hang up phone, Display Menu	CTRL ESC
OFF line ON line	CTRL SHIFT SPACE
Printer ON OFF	CTRL SHIFT P
QUIT	ESC ¦
HELP	ESC ~

Refer to the User's Manual for complete instructions on the use of your Information Terminal.

A complete, detailed description of the ESCape Sequences is presented in the ZT-1 Technical Manual.